

- 1 Quartz Operated Movement (battery not included, takes 1 AA battery)
- 1 Hour hand, 1 Minute Hand, 1 Second Hand (Sweep)

## Assembly Instructions:

- Slide rubber washer onto the shaft of the clock movement, pushing all the way down to the base.
- 2. Slide brass washer onto the shaft.
- 3. Slide clock face dial onto the shaft.
- 4. Slide brass washer onto the shaft.
- 5. Screw hex nut onto the shaft; be careful not to overtighten.
- 6. Slide hour hand onto the shaft all the way until it stops. Turn to the 12:00 position.

Clock Movement

Rubber

Clock Face Dial

Hour Minute

Second

- 7. Repeat with the minute hand and turn to 12:00.
- Press the stem of the second hand (sweep) into the top of the shaft until it stops. Turn to the 12:00 position.

**Note:** After completing assembly, ensure that the clock hands and sweep are not bent, as this will prevent proper rotation of the clock parts.

WARNING: CHOKING HAZARD—Small parts
Not for children under 3 years.

G19-294



PlaidOnline.com/clock-parts

©2011, 2019 PLAID ENTERPRISES, INC. • 09/19 P.O. BOX 7600 • NORCROSS, GA 30091-7600 (800) 842-4197 MADE IN CHINA